

### Lithurin® Dens Kullanma Talimatı

1. Pompa veya Maşrapa ile yüzeye eşit olarak uygulayınız.
2. Yumuşak bir fırça ile yüzeye yediriniz. Yüzeyi yaklaşık 15-20 dakika ıslak tutunuz.(+15-18C)
3. Tüm yüzey iyi bir reaksiyon için 15-20 dakika ıslak tutulmalı bu sayede Dens in beton içine işlenmesi sağlanmalıdır.
4. Eğer yüzey kurumaya başlarsa Lithurin Dens ekleyin. Emilme sürecinde yüzeyi tamamen ıslak tutunuz.
5. İşlem sonunda yüzeyde kalan fazla malzemeyi fırça ile alınız. (Fırçayı bastırarak malzemeyi uzaklaştırınız)
6. Zeminin emmediği tüm malzemeyi yüzeyden uzaklaştırınız.
7. Bu aşamaları 100 er metrekarelik alanlar şeklinde uygulayınız. ( 1Kişi = 100 m<sup>2</sup> 2Kişi = 200 m<sup>2</sup>)
8. Tüm yüzeylerin eşit şekilde malzemeye doyduğunu görünüz.

### Tüketim Miktarı

- Makine ile perdahlanan yüzeylerde yaklaşık 0,15 lt/ m<sup>2</sup>
- Makine ile perdahlanmayan yüzeylerde yaklaşık 0,2-0,4 lt/m<sup>2</sup>



ab lindec® endeavours to provide correct information about technical properties and handling of its products. However, while ab lindec® has no control over the way in which the products are mixed and laid, or the conditions under which they set, ab lindec® can in no way be held responsible. ab lindec® is only responsible for the quality of the products at the time of delivery.